

Tips, advice and ^{we} care

Whenever you dress up in this product, avoid any unnecessary stretching or pulling of the material in order not to damage the internal wiring system.

IMPORTANT INFORMATION - BATTERIES

- Consequently, any new battery should never be used before it has been completely charged.
- To ensure maximum battery life, it should be completely charged and discharged during the first 8-10 times.
- Remove the batteries from the product when no longer required.
- The batteries must be "summer-stored" in 100% charged condition, due to the built in security print that monitors the cell voltage, it discharges over a longer period.
- Make sure that the batteries are always fully charged before storage or use.

CHARGER

- For proper and safe use and charging – make sure that only the supplied Nordic Heat® charger and batteries are used.
- Red light = is charging, Green light = fully charged.

STORAGE

- Charge the batteries 100% before long lasting storage
 - Recharge at least once a year.
- Always store in a cool and dry place, away from sources of strong heat or open fire.
- Our high quality Li-on batteries, will like any other battery over time undergo reduction of charging capacity. Our batteries are guaranteed to last +500 charging cycles.

AIR TRANSPORT / TRAVEL:

Batteries must ALWAYS be carried in the hand luggage.

PROTECT THE ENVIRONMENT

Always dispose the battery at recycle station or in an approved battery box.

WASH & CARE

- Handwash and spot clean followed by hang drying.
- Machine wash 30°C gentle cycle using washbag with light spin only.
- No fabric softener.
- No wringing or twisting of the product.
- Always remove battery before washing :-)

SAFETY WARNINGS

- For the safety and protection of the electronic parts, needles or pointed objects are not to be inserted in the gloves.
- Keep it away from fire or excessive heat.
- When you remove the battery from the pocket, grab the plug and turn it clock- and counter wise while pulling gently, avoid pulling the cord.

WARRANTY

- Subject to normal usage, Nordic Heat® extends a 2-year warranty. Damage to fabric, wiring connections, or battery by misuse, accidents, fire, water, any unauthorized service or negligence is not covered.
- All repairs must be executed by Nordic Heat® Service Center, which invite you always to telephone ahead with your problem. Should Customer Service be unable to solve the matter on the telephone, the items in questions are to be forwarded to the Service Center.



Nordic Heat ApS · Kratbjerg 240 · DK-3480 Fredensborg · +45 2717 0000
Service@NordicHeat.dk · NordicHeat.dk · Nordic-Heat.com

Congratulations on your new Nordic Heat® Gloves

DEAR CUSTOMER

Thank you for taking the time to read this brief, but important user guidance. By following it, you will ensure optimal benefits of your Nordic Heat® product.

IMPORTANT INFORMATION!

Storage and use of Nordic Heat® Lithium-ion batteries

Never use the new batteries before they have been charged 100%.

Whenever the batteries are to be stored during the summer, make sure they are fully charged. Once again when the season starts, it is important that the batteries are fully charged before use. This will maintain the battery memory, extend the durability and provide you maximum capacity.

Nordic Heat® – Product optimization

Turn on the heat **before** you are getting cold, since the technology is designed to keep you warm, and not for warming you up. Your best starting point is warm hand, in heated glove.

It is beneficial to switch the setting to RED for a few minutes before use and then reducing to white or blue, this will help increase the battery life significantly. (NB: The gloves must not lie on top of each other during heating on red/high setting)

If you have any questions, please contact our service team at service@nordicheat.dk or +45 2717 0000


Enjoy your Nordic Heat® product!

Best regards
The Nordic Heat® Team



Nordic Heat® Battery heated Gloves with built-in battery indicator

Charge the batteries with USB-C/A via 220V or a powerbank before use



Blinking light on cabel = charger is ready (after 10 sek)
Red light = Charging
Green light = Fully charged

This way into the pocket




The easy accessible control button
Manages the on / off function and the desired heat level



Built-in battery indicator in real time

To turn on/off - press and hold the button for 2 sek



When the gloves are turned on, they start up at red light/high setting

Heating time approx.:

1,75 hours
Red light = High



3,5 hours
White light = Medium



+5 hours
Blue light = Low

